



# Light Vertical Multistage Centrifugal Pump

## Operation Manual





## **Contents**

I. Applications and conditions -----	1
II. Definition of model -----	2
III. Structure -----	3
IV. Installation and connection -----	10
V. Start-up, operation and maintenance -----	31
VI. Assemble and disassemble -----	33
VII. Fault finding and solution chart -----	36
VIII. Important notice -----	38

Read this manual carefully before install, start the pump

## I. Applications and conditions

Pumps of PSM model are non-self-priming vertical multistage centrifugal pumps. The features are high efficient, low noise, a little corrosive liquid resistance, compact structure, good appearance, small volume, light weight, easy to service, good seal performance, etc.

### 1. Applications

- Pumped liquids: Low viscosity, neutral, non-explosive liquids, not containing solid particles or fibres. The liquid must not attack the pump materials chemically.


- Boiler water supply and condensing system;
- Water treatment, filtration system;
- Food and beverage industries;
- Pressure boosting in high-rise buildings;
- Farmland irrigation, nursery irrigation and golf court irrigation;
- Industry cleaning system;
- Liquid conveying, circulation and boosting;
- Hot and cool water;

### 2. Operation conditions


- Medium temperature: Normal temperature type -15°C ~ +70°C;  
Hot water type -15°C ~ +120°C;
  - Flow: 0.4 ~ 180m<sup>3</sup>/h
  - Medium pH range: pH 5-9;
  - Maximum ambient temperature: +40°C;
  - Maximum altitude: 1000 m;
  - Minimum inlet pressure: Refer to CDL catalogue;
- Caution: When pumping liquids with a density and/or viscosity higher than that of water, use motors with correspondingly higher outputs, if required.

## II. Definition of model

1.P SM 1,2,3,4,8,16,20



1.P SM 32,42,65,85,120,150




### **III. Structure**

· The pump is mainly composed of motor, pump head, diffuser, impeller, cylinder, inlet & outlet chamber, pump shaft, mechanical seal and so on. Refer to Fig.1.

· Key parts of the pump, diffuser, impeller, cylinder, shaft, are all made of stainless steel. For PSM series, material of pump head and inlet & outlet chamber is made of cast iron. Or, they are made of stainless steel.


· Mechanical seal is a single face seal. Seal part is cemented carbides/carbon. Support part of support diffuser is made of tungsten carbide.

· Normally, pipes are connected by round flanges. Different types of connections are also available on demand of customer. See fig.2.




E-PSM1 , 2 , 3 , 4-111201

Figure 1 A




E-PSM 1, 2, 3, 4- 120702

Figure 1 B



**E-PSM8 , 12 , 16 , 20-111201**


Figure 1 C



1. Coupling guard  
 1a. Coupling guard(No nick)  
 2. Screw M4\*8  
 3a. Pump head  
 4. Diffuser  
 4a. Support diffuser  
 4b. Neck ring cover  
 4c. Neck ring  
 5. Coupling  
 5a. Inducer  
 7. Shaft pin  
 8. Nut M16, Washer 16  
 9. Hexagon socket head screw  
 10. Circlip cover  
 14. Strap  
 17. Impeller sleeve  
 22. First impeller cover  
 23. Nut M12, washer 12  
 25. Stay bolt  
 26g. Flange type Inlet & outlet chamber  
 26e. Oval flange type Inlet & outlet chamber  
 28. Drainage screw M10  
 29. Drainage nut  
 30. O ring 16\*3.3  
 31. O ring  
 33. Impeller sleeve(S)  
 33a. Impeller sleeve(L)  
 34a. Mechanical seal  
 36. Air vent nut  
 37. O ring 16\*2.65  
 38. Air vent screw  
 39. Screw, washer  
 40. Motor  
 46. Adjusting rubber  
 47a. Bearing  
 49. Impeller  
 50a. Top diffuser  
 51. Shaft  
 55. Cylinder  
 63. O ring retainer  
 65. Screw M8\*20  
 66. Oval flange  
 67. Oval flange cushion  
 68. Screw M12\*40  
 69. Screw


E-PSM8 , 12 , 16 , 20-111201

Figure 1 D



E-PSM32 , 42 , 65 , 85- 120702

Figure 1 E



CDL(F)120, 150-081101


Figure 1 F

## IV. Installation and connection

### 1.Handing

When lifting the entire pump with motor, follow these instructions:

- Pump with motor sizes 0.37-7.5kW:  
Lift the pump in the motor flange by means of straps or the like.
- Pump with motor sizes 11-75kW:  
Lift the pump by means of the motor eyebolts.





0.37-7.5kW



11-75kW

## 2.Pump installation



Pump size and dimension is as follows.





Round flange  
connection.



Cutting ferrule  
joint connection.



Pipe thread  
connection.



Oval flange  
connection.

Figure 2 Installation sketch

Table 1 Pump dimensions 50Hz

Model	Size (mm)						Weight (kg)
	B1	B2	B1+B2	D1	D2	D3	
PSM1-2	258	225	483	148	117	105	20
PSM1-3	276	225	501	148	117	105	20
PSM1-4	294	225	519	148	117	105	21
PSM1-5	312	225	537	148	117	105	21
PSM1-6	330	225	555	148	117	105	22
PSM1-7	348	225	573	148	117	105	23
PSM1-8	366	225	591	148	117	105	24
PSM1-9	384	225	609	148	117	105	25
PSM1-10	402	225	627	148	117	105	26
PSM1-11	420	225	645	148	117	105	26
PSM1-12	448	245	693	170	142	120	29
PSM1-13	466	245	711	170	142	120	30
PSM1-15	502	245	747	170	142	120	31
PSM1-17	538	245	783	170	142	120	33
PSM1-19	574	245	819	170	142	120	34
PSM1-21	610	245	855	170	142	120	35
PSM1-23	646	245	891	170	142	120	36
PSM1-25	692	290	982	190	155	140	42
PSM1-27	728	290	1018	190	155	140	43
PSM1-30	782	290	1072	190	155	140	45
PSM1-33	836	290	1126	190	155	140	49
PSM1-36	890	290	1180	190	155	140	51
PSM2-2	258	225	483	148	117	105	20
PSM2-3	276	225	501	148	117	105	20
PSM2-4	294	225	519	148	117	105	22
PSM2-5	312	225	537	148	117	105	23
PSM2-6	340	245	585	170	142	120	26
PSM2-7	358	245	603	170	142	120	26
PSM2-9	394	245	639	170	142	120	28
PSM2-11	430	245	675	170	142	120	29
PSM2-13	476	290	766	190	155	140	35
PSM2-15	512	290	802	190	155	140	36
PSM2-18	566	290	856	190	155	140	41
PSM2-22	638	290	928	190	155	140	42
PSM2-26	720	345	1065	197	165	160	52

Continued 50Hz

Model	Size (mm)						Weight (kg)
	B1	B2	B1+B2	D1	D2	D3	
PSM 3-2	258	225	483	148	117	105	20
PSM 3-3	276	225	501	148	117	105	20
PSM 3-4	294	225	519	148	117	105	21
PSM 3-5	312	225	537	148	117	105	21
PSM 3-6	330	225	555	148	117	105	23
PSM 3-7	348	225	573	148	117	105	24
PSM 3-8	376	245	621	170	142	120	27
PSM 3-9	394	245	639	170	142	120	28
PSM 3-10	412	245	657	170	142	120	28
PSM 3-11	430	245	675	170	142	120	29
PSM 3-12	448	245	693	170	142	120	30
PSM 3-13	466	245	711	170	142	120	31
PSM 3-15	502	245	747	170	142	120	32
PSM 3-17	548	290	838	190	155	140	38
PSM 3-19	584	290	874	190	155	140	39
PSM 3-21	620	290	910	190	155	140	42
PSM 3-23	656	290	946	190	155	140	43
PSM 3-25	692	290	982	190	155	140	44
PSM 3-27	728	290	1018	190	155	140	45
PSM 3-29	764	290	1054	190	155	140	46
PSM 3-31	810	345	1155	197	165	160	54
PSM 3-33	846	345	1191	197	165	160	55
PSM 3-36	900	345	1245	197	165	160	57
PSM 4-2	276	225	501	148	117	105	21
PSM 4-3	303	225	528	148	117	105	22
PSM 4-4	340	245	585	170	142	120	25
PSM 4-5	367	245	612	170	142	120	27
PSM 4-6	394	245	639	170	142	120	27
PSM 4-7	431	290	721	190	155	140	33
PSM 4-8	458	290	748	190	155	140	33
PSM 4-10	512	290	802	190	155	140	37
PSM 4-12	566	290	856	190	155	140	38
PSM 4-14	630	345	975	197	165	140	46
PSM 4-16	684	345	1029	197	165	140	48
PSM 4-19	765	355	1120	230	188	160	57
PSM 4-22	846	355	1201	230	188	160	59

Continued 50Hz

Model	Size (mm)						Weight (kg)
	B1	B2	B1+B2	D1	D2	D3	
PSM8-2/1	347	245	592	170	142	120	32
PSM8-2	347	245	592	170	142	120	32
PSM8-3	377	245	622	170	142	120	34
PSM8-4	417	290	707	190	155	140	40
PSM8-5	447	290	737	190	155	140	44
PSM8-6	477	290	767	190	155	140	45
PSM8-8	547	345	892	197	165	160	53
PSM8-10	607	355	962	230	188	160	64
PSM8-12	667	355	1022	230	188	160	66
PSM8-14	747	390	1137	260	208	200	81
PSM8-16	807	390	1197	260	208	200	84
PSM8-18	867	390	1257	260	208	200	93
PSM8-20	927	390	1317	260	208	200	94
PSM12-2	367	290	657	190	155	140	39
PSM12-3	397	290	687	190	155	140	43
PSM12-4	437	345	782	197	165	160	51
PSM12-5	467	345	812	197	165	160	53
PSM12-6	497	355	852	230	188	160	61
PSM12-7	547	390	937	260	208	200	73
PSM12-8	577	390	967	260	208	200	74
PSM12-9	607	390	997	260	208	200	76
PSM12-10	637	390	1027	260	208	200	83
PSM12-12	697	390	1087	260	208	200	87
PSM12-14	845	500	1345	330	255	350	157
PSM12-16	905	500	1405	330	255	350	161
PSM12-18	965	500	1465	330	255	350	164

Continued 50Hz

Model	Size (mm)						Weight (kg)
	B1	B2	B1+B2	D1	D2	D3	
PSM16-2	397	290	687	190	155	140	42
PSM16-3	452	345	797	197	165	160	50
PSM16-4	497	355	852	230	188	160	59
PSM16-5	562	390	952	260	208	200	76
PSM16-6	607	390	997	260	208	200	77
PSM16-7	652	390	1042	260	208	200	84
PSM16-8	697	390	1087	260	208	200	86
PSM16-10	875	500	1375	330	255	350	158
PSM16-12	965	500	1465	330	255	350	161
PSM16-14	1055	500	1555	330	255	350	174
PSM16-16	1145	500	1645	330	255	350	178
PSM20-1	387	245	632	170	142	120	33
PSM20-2	397	290	687	190	155	140	42
PSM20-3	452	355	807	230	188	160	58
PSM20-4	517	390	907	260	208	200	74
PSM20-5	562	390	952	260	208	200	76
PSM20-6	607	390	997	260	208	200	82
PSM20-7	652	390	1042	260	208	200	84
PSM20-8	785	500	1285	330	255	350	153
PSM20-10	875	500	1375	330	255	350	157
PSM20-12	965	500	1465	330	255	350	170
PSM20-14	1055	500	1555	330	255	350	172
PSM20-17	1190	550	1740	330	255	350	195

Continued 50Hz

Model	Size (mm)						Weight (kg)
	B1	B2	B1+B2	D1	D2	D3	
PSM32-1 0-1/PSM32-1 0	505	290	795	190	155	140	64/68
PSM32-20-2/PSM32-20	575	345/355	920/930	197/230	165/180	160	77/85
PSM32-30-2/PSM32-30	645	390	1035	260	208	200	100
PSM32-40-2/PSM32-40	715	390	1105	260	208	200	109
PSM32-50-2/PSM32-50	890	500	1390	330	255	350	181
PSM32-60-2/PSM32-60	960	500	1460	330	255	350	185
PSM32-70-2/PSM32-70	1030	500	1530	330	255	350	199
PSM32-80-2/PSM32-80	1100	500	1600	330	255	350	203
PSM32-90-2/PSM32-90	1170	550	1720	330	255	350	222
PSM32-100-2/PSM32-100	1240	550	1790	330	255	350	227
PSM32-110-2/PSM32-110	1310	575	1885	360	285	350	272
PSM32-120-2/PSM32-120	1380	575	1955	360	285	350	276
PSM32-130-2/PSM32-130	1450	650	2100	400	310	400	337
PSM32-140-2/PSM32-140	1520	650	2170	400	310	400	341
PSM32-150-2/PSM32-150	1590	650	2240	400	310	400	345
PSM32-160-2/PSM32-160	1660	650	2310	400	310	400	350
PSM42-10-1	561	345/355	906/916	197/230	165/188	160	83/90
PSM42-10							
PSM42-20-2	641	390	1031	260	208	200	105/110
PSM42-20							
PSM42-30-2	826	500	1326	330	255	350	183
PSM42-40-2	906	500	1406	330	255	350	197
PSM42-40							
PSM42-50-2	986	550	1536	330	255	350	221
PSM42-50							
PSM42-60-2	1066	575	1641	360	285	350	261
PSM42-60							
PSM42-70-2	1146	650	1796	400	310	400	320
PSM42-70							
PSM42-80-2	1226	650	1876	400	310	400	324
PSM42-80							
PSM42-90-2	1306	650	1956	400	310	400	328/352
PSM42-90							
PSM42-100-2	1386	650	2036	400	310	400	355
PSM42-100							
PSM42-110-2	1466	685	2151	460	340	450	426
PSM42-110							
PSM42-120-2	1546	685	2231	460	340	450	432
PSM42-120							
PSM42-130-2	1626	685	2311	460	340	450	438

Continued 50Hz

Model	Size (mm)						Weight (kg)
	B1	B2	B1+B2	D1	D2	D3	
PSM65-10-1	561	355	916	230	188	160	93
PSM65-10	561	390	951	260	208	200	105
PSM65-20-2	644	390	1034	260	208	200	110
PSM65-20-1	754	500	1254	330	255	350	182
PSM65-20	754	500	1254	330	255	350	182
PSM65-30-2	836	500	1336	330	255	350	196
PSM65-30-1	836	500	1336	330	255	350	197
PSM65-30	836	550	1386	330	255	350	221
PSM65-40-2	919	550	1469	330	255	350	225
PSM65-40-1	919	575	1494	360	285	350	258
PSM65-40	919	575	1494	360	285	350	258
PSM65-50-2	1001	650	1651	400	310	400	319
PSM65-50-1	1001	650	1651	400	310	400	319
PSM65-50	1001	650	1651	400	310	400	320
PSM65-60-2	1084	650	1734	400	310	400	325
PSM65-60-1	1084	650	1734	400	310	400	349
PSM65-60	1084	650	1734	400	310	400	349
PSM65-70-2	1166	650	1816	400	310	400	353
PSM65-70-1	1166	650	1816	400	310	400	353
PSM65-70	1166	685	1851	400	310	450	420
PSM65-80-2	1248	685	1933	460	340	450	424
PSM65-80-1	1248	685	1933	460	340	450	424
PSM85-10-1	571	390	961	260	208	200	105
PSM85-10	571	390	961	260	208	200	110
PSM85-20-2	773	500	1273	330	255	350	181
PSM85-20	773	500	1273	330	255	350	192
PSM85-30-2	865	550	1415	330	255	350	215
PSM85-30	865	575	1440	360	285	350	252
PSM85-40-2	957	650	1607	400	310	400	312
PSM85-40	957	650	1607	400	310	400	312
PSM85-50-2	1049	650	1699	400	310	400	336
PSM85-50	1049	650	1699	400	310	400	336
PSM85-60-2	1141	685	1826	460	340	450	407
PSM85-60	1141	685	1826	460	340	450	407

Continued 50Hz

Model	Size(mm)						Weight (kg)
	B1	B2	B1+B2	D1	D2	D3	
PSM120-10	840	500	1340	330	255	350	230
PSM120-20-2	1000	500	1500	330	255	350	245
PSM120-20-1	1000	550	1550	330	255	350	250
PSM120-20	1000	575	1575	360	285	350	285
PSM120-30-2	1160	650	1810	400	310	400	360
PSM120-30-1	1160	650	1810	400	310	400	360
PSM120-30	1160	650	1810	400	310	400	360
PSM120-40-2	1320	650	1970	400	310	400	400
PSM120-40-1	1320	650	1970	400	310	400	400
PSM120-40	1320	685	2005	460	340	450	460
PSM120-50-2	1480	685	2165	460	340	450	470
PSM120-50-1	1480	685	2165	460	340	450	470
PSM120-50	1510	760	2270	540	370	550	575
PSM120-60-2	1670	760	2430	540	370	550	585
PSM120-60-1	1670	760	2430	540	370	550	585
PSM120-60	1670	865	2535	580	410	550	705
PSM120-70-2	1830	845	2675	580	410	550	715
PSM120-70-1	1830	845	2675	580	410	550	715
PSM120-70	1830	845	2675	580	410	550	715
PSM 150-10-1	840	500	1340	330	255	350	230
PSM150-10	840	500	1340	330	255	350	235
PSM150-20-2	1000	550	1550	330	255	350	250
PSM150-20-1	1000	575	1575	360	285	350	295
PSM150-20	1000	650	1650	400	310	400	350
PSM150-30-2	1160	650	1810	400	310	400	360
PSM150-30-1	1160	650	1810	400	310	400	360
PSM150-30	1160	650	1810	400	310	400	385
PSM150-40-2	1320	685	2005	460	340	450	460
PSM150-40-1	1320	685	2005	460	340	450	460
PSM150-40	1350	760	2110	540	370	550	560
PSM 150-50-2	1510	760	2270	540	370	550	570
PSM150-50-1	1510	845	2355	580	410	550	690
PSM150-50	1510	845	2355	580	410	550	690
PSM150-60-2	1670	845	2515	580	410	550	700
PSM150-60-1	1670	845	2515	580	410	550	700
PSM150-60	1670	845	2515	580	410	550	700

Table 1 Pump dimensions 60Hz

Model	Size (mm)					Weight (kg)
	B1	B2	B1+B2	D1	D2	
PSM1-2	258	210	468	148	117	20
PSM1-3	276	210	486	148	117	20
PSM1-4	294	210	504	148	117	21
PSM1-5	312	210	522	148	117	22
CPSM1-6	330	210	540	148	117	23
PSM1-7	358	245	603	170	142	26
PSM1-8	376	245	621	170	142	27
PSM1-9	394	245	639	170	142	28
PSM1-10	412	245	657	170	142	29
PSM1-11	430	245	675	170	142	29
PSM1-12	448	245	693	170	142	30
PSM1-13	466	245	711	170	142	31
PSM1-15	512	290	802	190	155	37
PSM1-17	548	290	838	190	155	38
PSM1-19	584	290	874	190	155	41
PSM1-21	620	290	910	190	155	42
PSM1-23	656	290	946	190	155	43
PSM1-25	702	315	1017	197	165	51
PSM2-2	258	210	468	148	117	21
PSM2-3	286	245	531	170	142	24
PSM2-4	304	245	549	170	142	25
PSM2-5	322	245	567	170	142	26
PSM2-6	340	245	585	170	142	26
PSM2-7	368	290	658	190	155	32
PSM2-9	404	290	694	190	155	36
PSM2-11	440	290	730	190	155	37
PSM2-13	486	315	801	197	165	44
PSM2-15	522	315	837	197	165	45
PSM2-18	576	335	911	230	188	54

Continued 60Hz

Model	Size (mm)					Weight (kg)
	B1	B2	B1+B2	D1	D2	
PSM3-2	258	210	468	148	117	20
PSM3-3	276	210	486	148	117	21
PSM3-4	294	210	504	148	117	22
PSM3-5	322	245	567	170	142	25
PSM3-6	340	245	585	170	142	26
PSM3-7	358	245	603	170	142	27
PSM3-8	376	245	621	170	142	27
PSM3-9	404	290	694	190	155	33
PSM3-10	422	290	712	190	155	34
PSM3-11	440	290	730	190	155	34
PSM3-12	458	290	748	190	155	37
PSM3-13	476	290	766	190	155	38
PSM3-15	512	290	802	190	155	39
PSM3-17	548	290	838	190	155	40
PSM3-19	594	315	909	197	165	48
PSM3-21	630	315	945	197	165	49
PSM3-23	666	315	981	197	165	50
PSM3-25	702	335	1037	230	188	58
PSM4-2	286	245	531	170	142	24
PSM4-3	313	245	558	170	142	25
PSM4-4	350	290	640	190	155	31
PSM4-5	376	290	667	190	155	34
PSM4-6	404	290	694	190	155	35
PSM4-7	441	315	756	197	165	42
PSM4-8	468	315	783	197	165	42
PSM4-10	522	335	857	230	188	51
PSM4-12	576	335	911	230	188	52
PSM4-14	650	430	1080	260	208	64
PSM4-16	704	430	1134	260	208	66

Continued 60Hz

Model	Size (mm)					Weight (kg)
	B1	B2	B1+B2	D1	D2	
P5M8-2/1	347	245	592	170	142	32
P5M8-2	357	290	647	190	155	38
P5M8-3	387	290	677	190	155	41
P5M8-4	427	315	742	197	165	49
P5M8-5	457	315	772	197	165	50
P5M8-6	487	335	822	230	188	58
P5M8-8	567	430	997	260	208	71
P5M8-10	627	430	1057	260	208	80
P5M8-12	687	430	1117	260	208	82
P5M8-14	835	490	1325	330	255	153
P5M12-1	357	245	602	170	142	32
P5M12-2	367	290	657	190	155	41
P5M12-3	407	335	742	230	188	56
P5M12-4	457	430	887	260	208	69
P5M12-5	487	430	917	260	208	71
P5M12-6	517	430	947	260	208	77
P5M12-7	547	430	977	260	208	78
P5M12-8	665	490	1155	330	255	147
P5M12-10	725	490	1215	330	255	151
P5M12-12	785	490	1275	330	255	164
P5M12-14	845	490	1335	330	255	167

Continued 60Hz

Model	Size (mm)					Weight (kg)
	B1	B2	B1+B2	D1	D2	
PSM16-2/1	397	290	687	190	155	42
PSM16-2	407	335	742	230	188	56
PSM16-3	472	430	902	260	208	68
PSM16-4	517	430	947	260	208	75
PSM16-5	650	490	1140	330	255	148
PSM16-6	695	490	1185	330	255	150
PSM16-7	740	490	1230	330	255	161
PSM16-8	785	490	1275	330	255	163
PSM16-10	875	550	1425	330	255	186
PSM20-1	397	290	687	190	155	41
PSM20-2	407	335	742	230	188	56
PSM20-3	472	430	902	260	208	69
PSM20-4	517	430	947	260	208	79
PSM20-5	650	490	1140	330	255	148
PSM20-6	695	490	1185	330	255	150
PSM20-7	740	490	1230	330	255	162
PSM20-8	785	490	1275	330	255	163
PSM20-10	875	550	1425	330	255	187

Continued 60Hz

Model	Size (mm)					Weight (kg)
	B1	B2	B1+B2	D1	D2	
PSM32-10-1	505	315	820	197	165	73
PSM32-10	505	335	840	230	188	81
PSM32-20-2	575	430	1005	260	208	95
PSM32-20	575	430	1005	260	208	101
PSM32-30-2	645	490	1135	330	255	104
PSM32-30	750	490	1240	330	255	172
PSM32-40-2	820	490	1310	330	255	176
PSM32-40	820	490	1310	330	255	186
PSM32-50-2	890	490	1380	330	255	191
PSM32-50	890	550	1440	330	255	211
PSM32-60-2	960	550	1510	330	255	216
PSM32-60	960	550	1510	330	255	216
PSM32-70-2	1030	590	1620	360	285	255
PSM32-70	1030	590	1620	360	285	255
PSM32-80-2	1100	590	1690	400	310	259
PSM32-80	1100	660	1760	400	310	315
PSM32-90-2	1170	660	1830	400	310	319
PSM32-90	1170	660	1830	400	310	319
PSM32-100-2	1240	660	1900	400	310	324
PSM42-10-1	561	430	992	260	208	101
PSM42-10	561	430	992	260	208	106
PSM42-20-2	748	490	1238	330	255	178
PSM42-20	748	490	1238	330	255	188
PSM42-30-2	828	550	1378	330	255	213
PSM42-30	828	550	1378	330	255	213
PSM42-40-2	908	590	1498	360	285	253
PSM42-40	908	660	1568	400	310	309
PSM42-50-2	988	660	1648	400	310	313
PSM42-50	988	660	1648	400	310	313
PSM42-60-2	1068	660	1728	400	310	340
PSM42-60	1068	660	1728	400	310	340
PSM42-70-2	1148	700	1848	460	340	404
PSM42-70	1148	700	1848	460	340	404

Continued 60Hz

Model	Size (mm)					Weight (kg)
	B1	B2	B1+B2	D1	D2	
PSM65-1 0-1	561	430	991	260	208	109
PSM65-10	671	490	1161	330	255	177
PSM65-20-2	754	490	1244	330	255	187
PSM65-20	754	590	1344	360	285	248
PSM65-30-2	836	590	1426	360	285	252
PSM65-30	836	660	1496	400	310	313
PSM65-40-2	919	660	1579	400	310	336
PSM65-40	919	700	1619	460	340	398
PSM65-50-2	1001	700	1701	460	340	402
PSM85-10-1	571	490	1061	330	255	177
PSM85-1 0	571	490	1061	330	255	188
PSM85-20-2	773	550	1323	330	255	211
PSM85-20-1	773	590	1363	360	285	248
PSM85-20	773	660	1433	400	310	304
PSM85-30-2	865	660	1525	400	310	330
PSM85-30-1	865	660	1525	400	310	330
PSM85-30	865	700	1565	460	340	392
PSM85-40-2	957	700	1657	460	340	396

Continued 60Hz

Model	Size (mm)					Weight (kg)
	B1	B2	B1+B2	D1	D2	
PSM120-10-1	840	490	1330	330	255	235
PSM120-10	840	550	1390	330	255	250
PSM120-20-2	1000	660	1660	400	310	350
PSM120-20-1	1000	660	1660	400	310	350
PSM120-20	1000	660	1660	400	310	380
PSM120-30-2	1160	700	1860	460	340	445
PSM120-30-1	1160	700	1860	460	340	445
PSM120-30	1190	770	1960	510	370	545
PSM120-40-2	1350	845	2195	580	410	675
PSM120-40-1	1350	845	2195	580	410	675
PSM120-40	1350	845	2195	580	410	675
PSM120-50-2	1510	845	2355	580	410	690
PSM150-10-1	840	490	1330	330	255	235
PSM150-10	840	590	1430	360	285	280
PSM150-20-2	1000	660	1660	400	310	360
PSM150-20-1	1000	660	1660	400	310	380
PSM150-20	1000	700	1700	460	340	435
PSM150-30-2	1190	770	1960	510	370	545
PSM150-30-1	1190	845	2035	580	410	665
PSM150-30	1190	845	2035	580	410	665
PSM150-40-2	1350	845	2195	580	410	680

Table 2 Installation size

Size	Model	PSM													
		1	2	3	4	8	12	16	20	32	42	65	85	120	150
Round flange connecting	DN	25		32	40		50			65	80	100		125	150
	P1		60				80			107	120	150		175	203
	P		85		100	110		125		145	160	180		220	250
	P2		115		140	150		165		185	200	220		270	300
	n-d1		4- $\Phi$ 14				4- $\Phi$ 18				8- $\Phi$ 18			8- $\Phi$ 28	
	C		250			280		300		320	365	380		380	490
	E		75			80		90		105		140		180	200
	h		32			25		35		30		45		40	40
Nominal pressure						PN25				PN25-40		PN16		PN25-40	
Cutting Ferrule Joint connecting	D		42				60								
	C		210				260								
	E		50			80		90							
	h		20			25		35							
Pipe thread connection.	D		ZG1 $\frac{1}{4}$				ZG2								
	C		210				260								
	E		50			80		90							
	h		20			25		35							
Oval flange connection	D		G1		G1 $\frac{1}{4}$		G1 $\frac{1}{2}$								
	C		162			200									
	E		50			80									
	h		20			25									
	P		75			100									
	n-d1		2-M10×40			2-M12×45									
Footer size	k		22												
	G		100			130			170	190	199	275	385		
	G1		150			199			225	245	255	340	460		
	M		180			215			240	266	280	380	500		
	M1		210			247			298	330	348	472	600		
	d2		13						14			18	20		

The pump should be sited in a well ventilated and frost-free position. The distance between pump-motor and other objects should be at least 150mm , in order to cool the motor by fan with enough air.

· To reduce the head loss of inlet as least as possible, the inlet pipe shall be as short as possible.

· Ensure the check valve is installed in pipe line system before the pump installation. If pump is used for boiler water supply, a check valve must be installed in the piping between pump and boiler..

· Pump shall be installed in cement base or other similar base with suitable height. It can also be installed in fixed grounds or fixed brackets on wall. Pay attention not to let the weight of pipe system on pump to prevent pump from damage.

Caution: When installation, motor is not allowed to be hung upside down.

· Arrow on the inlet and outlet chamber shows the direction of flow of liquid through the pump. Check whether the liquid can flow easily before starting pump.

· Before pump installation, the inlet pipe line shall be cleaned. If there is impurities in the pipe, it is necessary to install a strainer at 0.5-1m in front of the pump inlet (particularly recommended for pump with flow less than  $8\text{m}^3/\text{h}$ ).

The air locks shall be avoided when installing the inlet pipe line. see Fig. 3




Figure 3

- If the outlet globe valve might be closed(or the flow is decreased to be zero), a bypass shall be installed in outlet pipeline to ensure adequate lubricating and cooling water to pass the pump.

## 2.Electrical connection

- The electrical connections should be carried out by an authorized electrician.

- To make sure the motor is suitable for the power supply, cables of the motor must be connected to power supply according to the Fig. on the terminal box and the motor nameplate.

- Motor shall be connected with a fast and effective motor starter, to ensure that the motor will not be damaged by lack of phase, unstable voltage or overload. The motor shall be earthed reliably.

Caution: Before take apart the terminal box cover or dismantle pump, make sure that the power supply is switched off.

## Warning - Electrical connection and safety devices


- The pump units should be connected to the power supply by the appropriately rated power cables according to the motor ratings.
- The pump units should always be equipped with safety devices as required in the standards (EN 809 and/or EN 60204-1) as well as by the national rules of the country where the pump is used.
- Despite the rules of any country, the power supply to the pump unit must be equipped with at least following electrical safety devices with appropriate ratings:
  - Emergency switch
  - Circuit breaker (as a supply disconnecting (isolating) device as well as an overcurrent protective device)
  - Motor overload protection

## Recommendation for Electrical Connection and Safety Devices

380V(50Hz/60Hz)						
No	Power input (kW)	Cable connection	Input current (A)	Cable spec (mm <sup>2</sup> )	Circuit breaker (A)	Thermal protector (A)
1	0.37	Y	1	0.75	5	1.2
2	0.55	Y	1.4	0.75	5	1.7
3	0.75	Y	1.8	0.75	5	2.2
4	1.1	Y	2.6	1	5	3.1
6	1.5	Y	3.5	1	10	4.2
8	2.2	Y	4.9	1.5	10	5.9
11	3	Y	6.3	1.5	10	7.6
13	4	Δ	8.2	2.5	20	9.8
15	5.5	Δ	11	2.5	20	13.2
16	7.5	Δ	15	4	20	18.0
17	11kw	Δ	21	4	25	25.2
18	15kw	Δ	29	6	32	34.8
19	18.5kw	Δ	35	10	40	42.0
20	22kw	Δ	41	16	60	49.2
21	30kw	Δ	55	16	60	66.0
22	37kw	Δ	68	25	80	81.6
23	45kw	Δ	82	35	100	98.4
25	55kw	Δ	100	70	160	120.0
26	75kw	Δ	134	70	160	160.8
27	90kw	Δ	160	90	200	192.0

The acoustic noise emission is around 85 dB(A).

- A、Before open the terminal box, please shut off the power supply to prevent from power shock.



- B、Before open the coupling guards, please stop pump firstly to prevent from hurts.



- C、When installing the pump, please fix the foundation bolts vertically to prevent from pump falls to hurt people.

- D、Please fill grease to the pump when it req.

For motor power is less than 5.5kW, it is free of filling grease. For motor power is equal or bigger than 5.5kW, please fill grease every 5000 running hours.



## V. Start-up, operation and maintenance

Caution: Read the label on the cylinder carefully before start-up.

1. Do not start the pump until it has been filled with water or liquid fully.

- Fill water in pump in inverse pouring system.

Close the pump outlet valve, release air vent screw on the pump head, and open the inlet valve slowly until stable water flows from the air vent screw. Then fasten the screw. Open the check valve completely in the inlet pipeline.

• In open system, fill water in pump when liquid surface is lower than pump.

Notice: A check valve shall be installed in the inlet pipe.

Close the pump outlet valve, release air vent screw and fill the liquid in pump through the air vent screw hole until the pump and inlet pipe line are filled with water fully. Fasten the air vent screw again.

Caution: Do not start the pump until it has been filled with liquid fully and air vented. Be careful the direction of the air vent screw hole. Make sure the flowing water will not hurt persons or pump or its parts. Especially, prevent from hurting for the hot water application.

### 2. Check the rotary direction

Switch on the power supply and view the rotary direction by viewing the motor fan. Arrow on the pump head indicates the correct direction of rotation. That is, from the motor end, pump shall run counter-clockwise.

### 3. Check before pump start-up

- Check whether the foundation bolt is fasten.
- Check whether pump is filled with water fully.
- Check whether the voltage of power supply is correct.
- Check whether it turns correctly.
- To make sure all pipe lines are connected tightly and can supply water normally.

- The valves in the inlet pipe line are completely opened and the outlet valve shall be opened slowly after the pump is started up.

- Check the operation pressure if pressure meter is installed.
- Check all the controls for normal operation. If the pump is controlled by pressure switch, check and adjust the starting pressure and stopping pressure. Check the full load current to make sure it not surpasses the max. Current.

### 4. Frequency of pump starts

Pump should not be started too frequently. It is suggested pump shall not be started more than 100 times per hour if the motor power is less or equal to 4kW. When motor power is big than 4kW, pump shall not be sta-

rted more than 20 times in one hour. If pump starts and stops too frequently, control device shall be checked and adjusted to make pump not start and stop too frequently. Also, it is necessary to check the installation.

5.Suggestion: When pump running, flow should be controlled at the range of 0.5-1.3 times of rated flow.

6.Pump which is installed according to this installation manual will work effectively and require a little maintenance.

• Mechanical seal will be adjusted automatically, the moving part and stationary part is lubricated and cooled by the transferring liquid. When replace the mechanical seal, the user needn't to disassemble the motor for power bigger than 7.5kW.

• The bearing in pump is lubricated by the transferring liquid.

#### 7.Frost Protecting

Pump can be used in the system with anti-frozen measures to water. If the pump is installed in easily frozen place, suitable antifreeze shall be added to the transferring liquid to prevent pump from being damaged. If antifreeze is not used, pump shall be stopped when it is frozen. Pumps which are not being used should be drained.

8.The following should be checked regularly for pump.

- Pump working and operating pressure
- Possible leakage
- Possible motor overheat
- Cleaning/replacement of all strainers
- The switch off time of motor when overload
- Frequency of starts and stops.
- All control operation

If malfunction is found, check system according to “Fault finding and solution chart”

9.Pump shall be cleaned and kept appropriately when it is not used for a long time.

10.Pump shall be prevented from being corrupted and damaged in storage.

## **VI. Assemble and disassemble**

### **1. PSM 1, 2, 3, 4**

· Put the circlip cover on the shaft, and then fit the sleeve, impeller, impeller sleeve, diffuser, support diffuser. Continue the assemble order till the last impeller is fitted. Then fit the impeller cover, washer, screw the nut. Pay attention to the position of the support diffuser, for less stages pump, the last one is support diffuser. For more stages pump, support diffuser should be increased accordingly, the distance of each support diffuser should be even, and put on the support sleeve and bearing with support diffuser.

· Put the inducer on the inlet & outlet chamber, and then fit the finished parts as above on the inducer.

· Fit the O-ring on the inlet & outlet chamber, put on the cylinder and the top diffuser.

· Put the pump head installed with O-ring, lining and corrugated spring on the cylinder. Screw the four nuts of the stay bolts on the base plate. Do not tighten one nut completely at one time, but tighten them symmetrically in turn.

· Fit the mechanical seal and tighten it , then install motor and coupling, screw the bolts in coupling(but not tightly),press the coupling and shaft down to the direction of the base plate. Then lift it about 1mm in reverse direction, tighten the screws. Note that the space between the two couplings should be equal.

· Tighten fixing bolts in mechanical seal, rotate the coupling to ensure that the shaft can rotate freely and not be choked.

Reverse the process above can disassemble a pump.

### **2.CDL and CDLF 8, 16, 16, 20**

· Put the circlip cover on the shaft, and then fit the sleeve, impeller, impeller sleeve, diffuser, support diffuser, bearing, support sleeve. Continue the assemble order till the last impeller is fitted, and then install the impeller cover, washer, tighten the nuts.

· Put the inlet & outlet chamber on the base plate, then put the O-ring, clamp plate, inducer on inlet & outlet chamber, then put the finished parts on the inducer, and put the top diffuser on the top, tighten nuts of straps. At last, put on the cylinder.

· Put the pump head installed with O-ring, lining and adjusting rubber on the cylinder, then tighten the four stay bolts symmetrically in turn.

· Fit the mechanical seal and tighten it , then install motor and coupling, screw the bolts in coupling(but not tightly),press the coupling and shaft down to the direction of the base plate. Then lift it about 1mm in reverse di-

rection, tighten the screws. Note that the space between the two couplings should be equal.

- Tighten fixing bolts in mechanical seal, rotate the coupling to ensure that the shaft can rotate freely and not be choked.

Reverse the process above can disassemble a pump.

### 3. PSM 32, 42, 65, 85

4.Put the inlet & outlet chamber on the base plate, fit flanges on inlet & outlet chamber at two sides, and fit the inducer.

- Put the first impeller on the shaft, tighten the nuts and put the impeller on the neck ring base of inducer, then put on the diffuser, impeller, support diffuser, until the top diffuser, then fix all the diffuser with the straps.

• shaft parts: fit the bottom sleeve, cover, washer on the shaft, tighten the bolts, fit bottom bearing on the inlet & outlet chamber, fit washer. Then put the shaft parts on the inlet & outlet chamber, fit on O-ring, lubricate the O ring and then put on the cylinder.

• Fit stay bolts on the base plate, then fit the O-ring, adjusting rubber, air vent gag on the pump head, and put the pump head on the stay bolts, then put on the washer and tighten all the nuts.

• Fit the mechanical seal on the pump head, then fit the seal cover, tighten the bolts, and the bolts in the seal. Lift the shaft and insert the adjusting slice.

- Fit the bracket and motor on the pump head.

Finally fit the coupling, tighten the bolts, and take out the adjusting slice. Rotate the coupling to ensure that the shaft can rotate freely and not be choked. Reverse the above process to disassemble a pump.

### 4.PSM 120, 150

5.Put the inlet & outlet chamber on the base plate, fit flanges on inlet & outlet chamber at two sides, and fit the inducer.

• Fit washer(PN58), shaft sleeve(PN17), inlet impeller sleeve(PN57), cover(PN18), washer, fasten the nut.

• Fit impeller shaft sleeve(PN16), impeller, fasten impeller nut((PN15), ensure the size is 14.3 as figure 4 shows.




Figure 4

- Put the shaft parts on the inducer, fit support diffuser, impeller sleeve, impeller, fasten impeller nut, then, fit diffuser, impeller, etc. till the last diffuser.
- Fit the top diffuser, use straps to fasten all diffusers. Fit O-ring on the inlet and outlet chamber, lubricate them and put on cylinder.
- Fit stay bolts on the base plate, fit O-ring on the pump head, adjusting rubber, air vent screw, etc. Then put pump head on the stay bolts, fit washer, fasten nut.
- Fit the mechanical seal on the pump head, then fit the seal cover, tighten the bolts, and tighten the bolts in the seal. Lift the shaft and insert the adjusting slice.
- Fit the bracket and motor on the pump head. Finally fit the coupling, tighten the bolts, and take out the adjusting slice. Rotate the coupling to ensure that the shaft can rotate freely and not be choked and loose. Reverse the above process to disassemble a pump.

## VII. Fault finding and solution chart

**Caution:** Before removing the terminal box cover and before any removal/dismantling of the pump, make sure that the power supply has been switched off.

Fault	Cause	Solution	Remarks
Motor does not run when started	a) Power supply failure. b) Fuses are blown. c) Motor is overloaded. d) Main contacts of starter are not connected well or the coil is defective. e) Control circuit is defective. f) Motor is defective.	a) Check power supply. b) Replace fuses. c) Check system. d) Replace motor starter. e) Check control circuit. f) Repair.	
Overload device of motor starter trips out immediately when power supply is switched on.	a) Fuses are blown. b) Contacts of overload device are faulty. c) Cable connection is loose or faulty. d) Motor winding is defective. e) Pump mechanically blocked.	a) Replace fuses. b) Check motor starter. c) Check cables and power supply d) Replace motor e) Check and repair pump	In the case of d) and e), users shall not disassemble the pump by themselves.
Overload device trips out occasionally.	a) The setting of overload is too low. b) Periodic power supply faults. c) Low voltage at peak times.	a) Reset overload setting b) Check power supply c) Add regulator.	
Motor starter has not tripped out but the pump does not run.	a) Contacts of starter are not contacted well or the coil is faulty. b) Control circuit are defective	a) Change motor starter b) Check control circuit	

Continued

Fault	Cause	Solution	Remarks
Pumped water does not flow constantly	a) Suction pipe is too small. b) There is not sufficient water in pump water inlet. c) Liquid level is low. d) Pump inlet pressure is too low compared with water temperature, pipeline loss and flow. e) Suction pipe is partly blocked by impurities.	a) Enlarge inlet pipeline b) Improve system and increase coming water c) Try to lift liquid level. d) Improve system and try to increase the inlet pressure. e) Check and clear impurities.	
Pump runs but gives no water.	a) Suction pipe is blocked by impurities. b) Foot valve or check valve is closed. c) Leakage in suction pipe. d) There is air in suction pipe or pump.	a) Check and clean suction pipe. b) Check and repair foot valve or check valve. c) Check and repair suction pipe. d) Refill liquid, release air.	
Pump runs backwards when switched off.	a) Leakage in suction pipe. b) Foot valve or check valve is defective. c) Foot valve is blocked in opened or partly opened position. d) There is air in suction pipe.	a) Check suction pipe b) Check and repair foot valve or check valve. c) Check and repair foot valve. d) Check and repair suction pipe and release air.	

Continued

Fault	Cause	Solution	Remarks
Abnormal vibration or noise from pump	a) Leakage in suction pipe.	a) Check and repair suction pipe.	In the case of e), users shall not disassemble the pump by themselves.
	b) Suction pipe is too small or suction pipe is partly blocked by impurities.	b) Enlarge or check suction pipe.	
	c) There is air in suction pipe or pump.	c) Refill liquid to the pump and vent air.	
	d) The comparison of the delivery head of device with delivery head of pump is very low.	d) Improve system or choose another pump model.	
	e) Pump mechanically blocked.	e)Check and repair pump.	

## VIII. Important notice

1. Customers will not be advised if this manual is updated.
2. Pump will be guaranteed for one year under normal operation with the correct model. Wearing part is not included.
3. Users shall be responsible for the damage if they disassemble the pumps by themselves in guaranteed period.











